



1994 Wiring Diagram - 600 XCR




ENGINE GND
STATOR
CDI MODULE
CUB415
SPARK PLUG
SPARK PLUG
ENGINE GND
IGNITION SWITCH
OFF
ON
BRN
BLK
HI/LOW SWITCH
LOW
HIGH
GRN
Y
Y/R
COLOR CODE
BLK = BLACK
BRN = BROWN
BLU = BLUE
GRN = GREEN
PUR = PURPLE
OR = ORANGE
Y = YELLOW
W = WHITE
R = RED
TWO COLOR WIRES ^ SHOWN WITH MAIN/TRACE COLORS.
EXAMPLE:
BLU/R = BLUE WITH RED TRACER
REGULATOR
CHASSIS GND
THUMBWARMERS
ACCESSORY SWITCH
IGNITION SWITCH
ACC. LIGHT
BRAKE LIGHT
HANDWARMERS DUAL HEAT
AUXILIARY SHUT-OFF SWITCH & THROTTLE SAFETY SWITCH
BRAKE LIGHT SWITCH
LOW OIL LEVEL SENDER
TEMP. SENDER
ENGINE GND
OIL LIGHT
TEMPERATURE LIGHT (RED LENS)
TACHOMETER
SPEEDOMETER
HI LO BEAM
HEAD LIGHT
HIGH BEAM INDICATOR
TAIL LIGHT GE194
BRAKE LIGHT GE80
TAIL LIGHT GE194


ENGINE GND
STATOR
CDI MODULE
IGNITION SWITCH
OFF
ON
HI/LOW SWITCH
LOW
HIGH
SPARK PLUG
ENGINE GND
REGULATOR
CHASSIS GND
THUMBWARMERS
ACCESSORY SWITCH
IGNITION SWITCH
ACC. LIGHT
BRAKE LIGHT
HANDWARMERS DUAL HEAT
AUXILIARY SHUT-OFF SWITCH & THROTTLE SAFETY SWITCH
BRAKE LIGHT SWITCH
LOW OIL LEVEL SENDER
TEMP. SENDER
ENGINE GND
TEMPERATURE LIGHT (RED LENS)
OIL LIGHT
HI LO BEAM
HEAD LIGHT
HIGH BEAM INDICATOR
TAIL LIGHT GE194
BRAKE LIGHT GE90
TAIL LIGHT GE194
TACHOMETER
SPEEDOMETER
COLOR CODE
BLK = BLACK
BRN = BROWN
BLU = BLUE
GRN = GREEN
PUR = PURPLE
OR = ORANGE
Y = YELLOW
W = WHITE
R = RED
TWO COLOR WIRES ARE SHOWN WITH MAIN/TRACE COLORS.
EXAMPLE:
BLU/R = BLUE WITH RED TRACER


COLOR CODE
BLK = BLACK
BLU = BLUE
BRN = BROWN
GRY = GRAY
GRN = GREEN
PUR = PURPLE
LGR = LIGHT GREEN
OR = ORANGE
P = PINK
Y = YELLOW
W = WHITE
R = RED
TWO COLOR WIRES ARE SHOWN WITH MAIN/TRACE COLORS
EXAMPLE: BLU/R = BLUE WITH RED TRACER
POLARIS ELECTRONIC FUEL INJECTION
POLARIS HARNESS - FUJI HARNESS
ACS LR-36
CDI MODULE CU 6415
12V BATTERY
STATOR
REGULATOR
SPARK PLUGS
ENGINE GND.
CHASSIS GND
KILL SWITCH
SPEED CONTROL ASSURANCE SW. (2)
IGNITION SWITCH
AIR TEMP. SENSOR
WATER TEMP. SENSOR
SELF SHUT OFF RELAY (BLACK)
FUEL PUMP RELAY (BLACK)
FUEL PUMP
THROTTLE POSITION SENSOR
DROPPING RESISTOR
INJ#1 INJ#2
TEMP/BATTERY WARNING LIGHTS
TACHOMETER
SPEEDOMETER
LOW OIL LEVEL SENDER
OIL/BRAKE LIGHT
HEAD LIGHT
HIGH/LOW BEAM SWITCH
HIGH BEAM LIGHTS
LOW BEAM LIGHT
TAIL LIGHT
THUMB WARMERS
HANDWARMERS DUAL HEAT
ROCKER SWITCH
OFF/ON
LOW
HIGH
OFF
E.S. IGNITION SWITCH
IGNITION SWITCH
HI/LOW SWITCH
ISOLENOID
ECU
PIN # & WIRE COLOR
SCI MONITOR
ENGINE GND
POLARIS HARNESS - FUJI HARNESS