


IGNITION SWITCH
KILL SWITCH
IGNITION SWITCH
KILL SWITCH
(RXL TOURING ONLY)
CIRCUIT BREAKER
12V BATTERY
FUSIBLE LINK
ENGINE GND
REGULATOR RECTIFIER
CDI MODULE CU 2178
SPARK PLUGS ENGINE GND
IGNITION COILS
STATOR ENGINE GND
REGULATOR
ENGINE GND
IGNITION SWITCH
CRANK CASE TEMP. SENSOR
AIR TEMP. SENSOR
SPEED CONTROL ASSURANCE SW.(2)
STARTER RELAY CHASSIS GND
ENGINE GND
STARTER
POLARIS ELECTRONIC FUEL INJECTION
EFI RELAY (BROWN)
SELF SHUT OFF RELAY (BLUE)
FUEL RELAY (BLUE)
FUEL PUMP
HEAD LIGHT
HI BEAM IND.
HI-LO SWITCH
HI/LOW SWITCH
BRAKE LIGHT SWITCH
HANDWARMER SWITCH
HANDWARMERS DUAL HEAT
TAIL LIGHT
BRAKE LIGHT
TAIL LIGHT
ACC. LIGHT
DROPPING RESISTOR
INJ#1
INJ#2
INJ#3
SCI MONITOR
TACHOMETER
SPEEDOMETER
LOW OIL LEVEL SENDER
OIL/BRAKE LIGHT
TEMP. LIGHT
TEMPERATURE SENDER
ENGINE GND
SENDER
REGULATOR (LR 5)
FUEL GAUGE
(RXL TOURING ONLY)
COLOR CODE
BLK = BLACK
BLU = BLUE
BRN = BROWN
GRY = GRAY
GRN = GREEN
PUR = PURPLE
LG = LIGHT GREEN
OR = ORANGE
P = PINK
Y = YELLOW
W = WHITE
R = RED
TWO COLOR WIRES ARE SHOWN WITH MAIN/TRACE COLORS
EXAMPLE: BLU/R = BLUE WITH RED TRACER


CDI MODULE CU TBA
IGNITION COILS
SPARK PLUGS ENGINE GND
IGNITION SWITCH
HIGH/LOW SWITCH
STATOR
REGULATOR
LRB
CHASSIS GND
THUMBWARMERS
ACCESSORY SWITCH
HANDWARMERS DUAL HEAT
ACC. LIGHT
IGNITION SWITCH
AUXILIARY SHUT OFF SWITCH & THROTTLE SAFETY SWITCH
BRAKE LIGHT SWITCH
BRAKE LIGHT
ENGINE GND
LOW OIL LEVEL SENDER
TEMP. SENDER
OIL LIGHT
TEMPERATURE LIGHT (RED LENS)
TACHOMETER
SPEEDOMETER
TAIL LIGHT GE181
BRAKE LIGHT GE84
TAIL LIGHT GE181
HI LO BEAM
HEAD LIGHT
HIGH BEAM INDICATOR
COLOR CODE
BLK = BLACK
BRN = BROWN
BLU = BLUE
GRN = GREEN
PUR = PURPLE
OR = ORANGE
Y = YELLOW
W = WHITE
R = RED
TWO COLOR WIRES ARE SHOWN WITH MAIN/TRACE COLORS.
EXAMPLE: BLU/R = BLUE WITH RED TRACE

BODY ELECTRICAL
1995 Wiring Diagram - StarLite / Lite / GT

