



ENGINE GND.
STATOR
CDI MODULE
CU 6415
SPARK PLUG
ENGINE GND.
SPARK PLUG
IGNITION SWITCH
OFF
ON
HIGH LOW SWITCH
LOW
HIGH
REGULATOR
LRB
CHASSIS GND.
ACCESSORY SWITCH
THUMBWARMERS
HANDWARMERS SINGLE HEAT
IGNITION SWITCH
REVERSE LIGHT SWITCH
REVERSE LIGHT
AUXILIARY SEAT OFF SWITCH & THROTTLE SAFETY SWITCH
BRAKE LIGHT SWITCH
LOW OIL LEVEL SENDER
TEMP. SENDER
ENGINE GND.
TEMPERATURE LIGHT (RED LENS)
OIL LIGHT
TACHOMETER
SPEEDOMETER
HI LO BEAM
HEAD LIGHT
HIGH BEAM INDICATOR
TAIL/BRAKE LIGHT GE1157
COLOR CODE
BLK = BLACK
BLU = BLUE
BRN = BROWN
GRN = GREEN
OR = ORANGE
Y = YELLOW
W = WHITE
R = RED
PUR = PUR
TWO COLOR WIRES ARE SHOWN WITH MAIN/TRACE COLORS.
EXAMPLE: BLU/R = BLUE WITH RED TRACER

1994 Wiring Diagram - XLT / XLT SP / XLT SKS / XLT Special XTRA




POLARIS
ELECTRONIC
FUEL
INJECTION
IGNITION SWITCH
KILL SWITCH
CIRCUIT BREAKER
12V BATTERY
REGULATOR RECTIFIER
CDI MODULE CU 2178
FUSIBLE LINK
ENGINE GND
SPARK PLUGS
STATOR
IGNITION COILS
REGULATOR
HEAD LIGHT
HI BEAM IND.
HI-LO SWITCH
BRAKE LIGHT SWITCH
HANDWARMER SWITCH
HANDWARMERS DUAL HEAT
TAIL LIGHT
BRAKE LIGHT
ACC. LIGHT
EFI RELAY (BROWN)
SELF SHUT OFF RELAY (BLUE)
FUEL RELAY (BLUE)
FUEL PUMP
DROPPING RESISTOR
INJ#1
INJ#2
INJ#3
SCI MONITOR
CRANK CASE TEMP. SENSOR
AIR TEMP. SENSOR
SPEED CONTROL ASSURANCE SW.(2)
STARTER RELAY
STARTER
(RXL TOURING ONLY)
TACHOMETER
SPEEDOMETER
LOW OIL LEVEL SENDER
OIL/BRAKE LIGHT
TEMP. LIGHT
TEMPERATURE SENDER
FUEL GAUGE
SENDER
REGULATOR (LR-5)
(RXL TOURING ONLY)
COLOR CODE
BLK = BLACK
BLU = BLUE
BRN = BROWN
GRY = GRAY
GRN = GREEN
PUR = PURPLE
LG = LIGHT GREEN
OR = ORANGE
P = PINK
Y = YELLOW
W = WHITE
R = RED
TWO COLOR WIRES ARE SHOWN WITH MAIN/TRACE COLORS
EXAMPLE:
BLU/R = BLUE WITH RED TRACER